



DOCUMENTATION

zomo MC1000



1 - Play / Pause

2 - Cue

3 - Shift

4 - Sync

5 - Loop Controls

(Increase/Decrease)

6 - HPF/LPF Dedicated channel HP/LP filter

7 - Load song (L / R)

6 - HPF/LPF Dedicated channel HP/LP filter

7 - Load song (L / R)

8 - Browser library scroll. Push to select file.

9 - Back Toggles focus between Library and Playlist

10 - Change View-Mode

11 - Pitchbend + / -

12 - open file archive groups